
# 3-5. Using the interior lights **Interior lights list**




Front interior lights  $(\rightarrow P. 375)$ 

- Remote touch light (when the "POWER" switch is in ACCESSORY or ON mode)
- 4 Rear interior light
- **5** Door courtesy lights
- 6 Scuff lights (if equipped)
- **7** Footwell lights
- Outer foot lights


# Interior lights

## Front



- Turns the lights on/off linked to door positions
- 2 Turns the lights on/off

#### Rear



- 1 Turns the light on
- Turns the light on/off linked to door positions

# Personal lights



Turns the light on/off

## ■ Illuminated entry system

The lights automatically turn on/off according to "POWER" switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are opened/closed.

## ■ To prevent 12-volt battery discharge

If the interior lights remain on when the door is not fully closed and the interior light switch (door position on/ off) is on, the lights will go off automatically after 20 minutes.

#### ■ Customization

Settings (e.g. the time elapsed before the lights turn off) can be changed. (Customizable features  $\rightarrow$  P. 584)